

W113 PARTS INERCHANGABILITY

ENGINES

250SL	129982	ALSO 129980,981
280SL	130983	ALSO 130980,981

DRIVE TRAIN

MOTOR MOUNTS ALL	180-223-1012	MOST 110,108,109,111 WITH SIX CYLINDER
TRANS MOUNTS ALL	120-223-0412	DITTO
CLUTCH PLATE 230,250SL	000-250-9604	DITTO UP TO 1968
CLUTCH PLATE 280SL	001-250-4204	ALL M130E AFTER 1968
CLUTCH DISC ALL	004-250-1703	ALL M129,130 ENGINES
T/O BEARING 230,250SL	111-250-0115	108,110,111, TO 1968
T/O BEARING 280SL	000-250-0515	108,109,111 1968 ON
SLAVE CYLINDER 230,250	000-295-1907	108,110,111. TO 1968
SLAVE CYLINDER 280SL	000-295-4207	108,110,111 1968 ON
SHIFT BOOT ALL	111-268-0497	108,109,111 TO 1969
AUTOMATIC 230,250SL	113-270-0101	108 W/M129 ENGINE
AUTOMATIC 280SL	113-270-0901	108 W/M130 ENGINE
GAS PEDAL ALL	110-300-0002	108,110,111 W/SIX
BRAKE SWITCH ALL	112-300-0241	108,110,111
RUBBER STOPS ALL	110-320-0544	108,110,111
FOR REAR SUSPENSION		
GEAR SHIFT MANUAL	111-268-0324	108,109,111 TO 1969
GEAR SHIFT AUTO	111-267-0001	DITTO
FRONT CROSSMEMBER	111-330-3042	108,109,110,111
SUBFRAME MT. KIT	108-330-0275	DITTO
KINGPIN KIT	111-586-0033	DITTO
UPPER INNER BUSHING KIT	110-330-0018	DITTO
UPPER OUTER BUSHING KIT	110-330-0218	DITTO
LOWER INNER BUSHING KIT	110-330-0118	DITTO
LOWER OUTER BUSHING KIT	110-330-0318	DITTO
TIE ROD ENDS, LEFT	000-338-5010	DITTO
TIE ROD ENDS, RIGHT	000-338-5210	DITTO
STEERING SHOCK	000-463-5132	DITTO
DRAG LINK	110-460-0205	DITTO
IDLER ARM KIT 230,250	111-460-0050	108,110,111, TO 1968
IDLER ARM KIT 280SL	126-460-0819	114,115,123,116,126
REAR DIFF W/3.92		108,110,111 W/ SIX
REAR DIFF MOUNT	110-350-0675	108,110,111 W/SIX
FLEX JOINT KIT	108-410-0115	DITTO
FRONT CALIPERS (ATE)	001-421-8198	108,111 W/ SIX
	8298	
REAR CALIPERS	000-420-4683	108,111 W/SIX
	4783	
FRONT ROTOR 230SL	110-421-0112	110,early 111
FRONT ROTOR 250,280SL	115-421-1112	108,109,114,115
PARKING BRAKE SHOE	126-420-0120	DITTO
BRAKE BOOSTER 230-280	000-430-5530	230,250S,280S,300SE
UP TO 006618		
BRAKE BOOSTER LATE 280	002-430-6830	280S,280SE AFTER '68

UNDERHOOD ITEMS

POWER STEERING PUMP	127-460-1280	110,111,108,109
RESERVOIR	127-460-0383	108,109,111W/INJ
POWER STEERING HOSE	109-997-0882	DITTO
POWERSTEERING BOX	109-460-1001	DITTO
MANUAL STEERING BOX	111-460-3401	110,111,108
GAS TANK SENDING UNIT	110-542-1204	108,109,110,111,112
LOCKING GAS CAP	000-471-2030	108,109
FUEL PUMP	001-091-5201	AL FUEL INJ TO '72
RAD EXP TANK 250,280	109-500-0049	230S,300SE,SEL
FUEL HOSES	111-476-0926	ALL FUEL INJ TO '72
	108-476-0026	DITTO
HORNS	002-542-0020	110,111,108 TO '68
	002-542-0120	DITTO
RELAY	000-542-5819	108,110,111,109
COVER FOR SUBFRAME	110-683-0010	110,108,109 TO '68
WINDSHIELD WASHER PUMP	108-869-0021	108,109,111
WINDSHIELD WIPER ARM	110-820-0544	110,111,108 TO '68
230-250SL TO 2979	110-820-0644	DITTO
HOOD CATCH	110-880-0860	110,108,109,111
DISTRIBUTOR TO '70	002-158-3801	108,109,111 W/INJ
COIL NON TRANSITORIZED	000-158-0603	DITTO
STARTER	002-151-1501	114,115,108,107,
ALTERNATOR	002-154-4602	114,115,110,108
VOLTAGE REGULATOR	002-154-2806	110,108,109,111
WIPER MOTOR	110-820-0442	190C,DC,200,D,

CHROME

DOOR HANDLES	110-766-0701	110,111 TO '68
(MUST CHANGE PLUNGER)	0801	DITTO
DOOR LOCKS	110-720-1535	DITTO
	1635	DITTO
SKIRTING AROUND LOCK	111-723-5124	DITTO
	5224	DITTO
DOOR LATCH 230,250	110-720-1104	DITTO
(ON REAR QTR)	1204	DITTO
INTERIOR HANDLE	110-760-0961	DITTO
	1061	DITTO
WELL PLATE	110-766-0511	DITTO
	0611	DITTO
WINDOW CRANK 230,250	110-760-0402	DITTO
DECK LID HANDLE	111-758-5002	DITTO
INSIDE MIRROR 230,250	111-810-5017	DITTO
SIDE MIRROR LEFT	110-810-0916	DITTO
(230,250) RIGHT	110-810-1016	DITTO