

# Additional Timer Relay for Hot Start

Four new wires needed

- From terminal 85 on CSV relay to terminal 8 on timer relay
- From terminal 86 on CSV relay to terminal 2 on timer relay
- Timer relay 6 to timer relay 7
- Timer relay 7 to ground

When energized by Start (50) via CSV relay, terminal 6 (ground) is connected to terminal 8 for an adjustable length of time. This provides ground to the CSV relay, thus the CSV will operate for the adjustable length of time.

