


## RHD Bulkhead grommet locations



1. Accelerator pedal grommet
2. Half circle grommet
3. Clutch pipe (Manual) & temp gauge
4. Oil pressure line
5. Main harness grommet
6. Heater Core grommet
7. Heater core grommet

8. Heater Valve grommet
9. Tacho & Speedo cables grommet
10. Bonnet Release Cable & Washer Hose
11. Square grommet under wiper motor
12. Half Circle grommet
13. Wiper Motor
14. Fuse Box