

## Ignition System Components Recommendation 280SL

### Moderate Climate

	Original Distributor	123 Distributor
Coil	Red with 1.8Ω resistor. Blue with transistorized ignition	Red (or minimum 1Ω) without resistor
Leads type	Copper core Beru, Bosch	Copper core Beru, Bosch
Cap connectors resistance	0 resistance. 1kΩ for transistorized ignition	0 resistance. 1kΩ for transistorized ignition
Spark plugs connectors type/resistance	1kΩ resistance Beru, Bosch 5kΩ for transistorized	1kΩ resistance Beru, Bosch 5kΩ for transistorized
Spark plugs in town/relaxing driving	BP5ES (TBC)	BP5ES (TBC)
Spark plugs highway/freeway/sport driving		

### Warm Climate

	Original Distributor	123 Distributor
Coil	Red with 1.8Ω resistor. Blue with transistorized ignition.	Red (or minimum 1Ω) without resistor
Leads type	Copper core Beru, Bosch	Copper core Beru, Bosch
Cap connectors resistance	0 resistance. 1kΩ for transistorized ignition	0 resistance. 1kΩ for transistorized ignition
Spark plugs connectors type/resistance	1kΩ resistance Beru, Bosch 5kΩ for transistorized	1kΩ resistance Beru, Bosch 5kΩ for transistorized
Spark plugs in town/relaxing driving		
Spark plugs highway/freeway/sport driving		

Symptoms if your plugs are too hot:

- ....
- ..
- ..

Symptoms if your plugs are too cold:

- ....
- ...
- ...

### Remarks:

- Spark plug heat value/range NGK/Bosch coding difference explanation on the next page.
- 123 Setting for Euro cars: curve 8 or table on the following pages. For the US cars: E curve.
- On 123 Ignitoin pages carbon core leads are offered as well as WR (resistor) plugs. The Forum recommendations are in the table above.
- Details regarding leads and connectors can be found in the Technical Manual <https://www.sl113.org/wiki/Electrical/SparkPlugWires>
- Details regarding coils can be found in the Technical Manual <https://www.sl113.org/wiki/Electrical/IgnitionCoil>




# Spark Plugs Heat Range Explanation

## Spark plug heat dispersal

The heat that the electrode section of the spark plug receives due to combustion is dispersed through the path in the figure. The degree to which a spark plug disperses the heat it receives is called its "heat range". Spark plugs with a high degree of heat dispersal are called high heat range (cold type) and those with a low degree of heat dispersal are called low heat range (hot type). This is largely determined by the temperature of the gas inside the combustion chamber and the spark plug design.

Addition from Members:

- "Hot" spark plug – less heat dispersing, low heat range. "Cold" spark plug – more heat dispersing, high heat range.
- Different classification of Bosch and NGK:
  - Bosch W7DC is colder than W9DC – the higher the number the hotter the spark plug (the less heat dispersion)
  - NGK BP5ES is hotter than BP7ES – the lower the number the hotter the spark plug (the less heat dispersion)
  - The heat range for Bosch and NGK spark plugs are similar at 7: BP7ES = W7DC




## Spark plug temperature and vehicle speed (1)

The relationship between the spark plug temperature and vehicle speed and heat range is expressed with a graph like that in the figure. There are restrictions on the temperatures at which spark plugs can be used: the lower limit is the self-cleaning temperature and the upper limit is the pre-ignition temperature. A spark plug only functions completely when its center electrode temperature is between these temperatures of about 500°C and 950°C.

## Spark plug temperature and vehicle speed (2) - self-cleaning temperature


When the center electrode temperature is 500°C or lower, free carbon generated when the fuel does not combust completely is deposited on the surface of the insulator. Therefore, the insulation between the insulator and the housing falls, electricity leaks occurs, the spark across the gap is incomplete, causes ignition failures.

This temperature of 500°C is called the self-cleaning temperature because above this temperature the carbon is naturally burnt away completely by combustion.



## Spark plug temperature and vehicle speed (3) - pre-ignition temperature

When the center electrode reaches 950°C or higher, pre-ignition (early ignition) occurs, meaning that the electrode serves as a heat source and ignition occurs without a spark. Therefore, output falls and this can reach the level of electrode wear and insulator damage.




## Spark plug temperature and vehicle speed (4)

Low heat range spark plugs have center electrode temperatures that rise easily and even at low-speed, they easily reach the self-cleaning temperature, so carbon is not deposited easily on the insulator section. On the other hand, high heat range spark plugs have center electrode temperatures that do not rise easily, so they are unlikely to reach the pre-ignition temperature even at high speed.

Therefore, this type of spark plug is generally used for high speed, high output engines.

That is why it is necessary to select spark plugs with the appropriate heat range for the engine characteristics, running conditions, etc.




# 123 Settings

Note: these are Members recommendations. May turn out you need to come up with your own ones that would work best for your car.

## Euro cars


- Curve 8\*, or



\*For the Euro cars, program 8 will work, if the original European throttle body, sourcing vacuum from below the throttle body, is intact, or have been installed as a Euro-conversion of a US car.

## US Cars

- Curve E\*, or



\*In terms of the US configuration cars, then for the standard 123ignition, program E would be right, given that all the vacuum shut-off gears and relays are still working correctly (though they rarely are). I think Mike uploaded some US curves for the programmable 123ignition in another thread.